ALARMS - 5

Repeat the process for the other alarm altitudes and once all values are set, scroll to and select **Save**. The new alarm settings are now active.

See the N3 User Guide for a detailed explanation of setting alarm group names and altitudes. You may also customize your alarm settings using the Neptune Maintenance Utility (NMU).

USING N3 AS A VISUAL ALTIMETER

HAND MOUNT - 1

If you wish to use the N3 as a visual altimeter, we suggest you use the hand mount provided.

The strap goes between the back plate and plastic top of the hard mount case.

HAND MOUNT - 2

You can use the N3 on the right or left hand. To change the orientation of the display, use the **Flip** function. Scroll to and select **Display Opt**, then scroll to and select **Flip LCD**.

WRIST MOUNT

Feed the wrist strap between the back plate and plastic top of the hard mount case.

Do not use the hand mount and wrist mount together. Use one or the other.

To preserve battery charge when using the N3 exclusively as a visual altimeter, we recommend disabling alarms. To **disable freefall alarms**, scroll to and select **Alarms**, then scroll to and select **Disable FF Alrm**.

To use the N3 on night jumps, turn on the **Backlight**. Scroll to and select **Display Opt**. Select **Backlight On/Off** at the top of the screen.

Note: when turned on, the backlight will stay on for only three seconds while the N3 is on the ground, to conserve battery life. The backlight will stay on in freefall and under canopy. We recommend that you fully charge your N3 before making a night jump.

Parachuting is a hazardous activity that can result in injury or death. An altimeter may malfunction, even when properly designed, built, assembled, maintained and used. Do not rely upon an altimeter for your safety. Your altimeter must only be considered as an aid when checking your altitude. The displayed altitude may not be correct during both ascent and descent – a visual cross reference with the ground should be used in combination with the altimeter.

QUICK START GUIDE

Rev. D

Thank you for buying an Altimaster N3!

You are now the proud owner of an Altimaster N3, the next generation of skydiving instruments. The complete N3 User Guide, in Acrobat (pdf) format, can be found on our website www.alti-2.com.

Please register your Altimaster N3 on-line at www.alti-2.com.

WARRANTY

To activate the warranty, please register your N3 on-line at **www.alti-2.com**. Don't forget to let us know who recommended this product to you.

WARNING!

N3's default functions are designed for normal skydives. If you are undertaking any kind of specialty jump, please call us for appropriate settings.

We strongly suggest that you avoid using either Manual Mode or DZ Setup functions until you have read the user manual regarding the correct use of these features.

CHARGING

Before using your new N3 for the first time, **charge it overnight.**

Using the USB cable supplied, connect the N3 to a USB charger or computer.

Allow 2 hours for a full charge on subsequent charges.

BUTTONS & NAVIGATION

Top and bottom buttons scroll the menus and increase/decrease values.
To select an item press the middle button.
Hold top or bottom buttons to review jump log.
To go back to the previous screen press and hold the middle button until the screen changes.

Parachuting is a hazardous activity that can result in injury or death. An altimeter may malfunction, even when properly designed, built, assembled, maintained and used. Do not rely upon an altimeter for your safety. Your altimeter must only be considered as an aid when checking your altitude. The displayed altitude may not be correct during both ascent and descent – a visual cross reference with the ground should be used in combination with the altimeter.

GROUND SCREEN

The Ground Screen shows time, date and temperature.

Icons shown indicate:
- Logbook enabled.
- Alarms enabled.
- Battery fully charged.

N3 has a 30 min timeout on the display. Press any button to reactivate the display.

MAIN DISPLAYS

There is no need to turn the N3 on to make a jump. Your N3 will automatically go into climb mode when the aircraft takes off. Once you exit the aircraft, it will switch to freefall display; it is not possible to exit from this mode while in freefall. If enabled, canopy mode will be displayed once you have deployed your parachute. (Climb screen shown at left.)

SET NEXT JUMP NUMBER – 1

To change the starting number on your jump log, go to **Log Admin** on the Menu screen. The **Set Next Jump** number is highlighted. Press the middle button to **Set Next Jump** number.

SET NEXT JUMP NUMBER - 2

Press the middle button until the desired number you wish to change is enlarged. Increase or decrease to the number desired using the top and bottom buttons. Once you have the desired jump number, press the middle button until **OK** is highlighted. Press the middle button again to save the new number. (Remember to press and hold the middle button to go back to the main screen)

OTHER SETTINGS

Time and Date: Menu > Clk/Timers > Set Time; Menu > Clk/Timers > Set Date

Previous FF and CP time: Menu > Log Admin

Display Altitude in Metres: Menu > Display Opt > Disp Alt in m

Display Temperature in Celsius: Menu > Display Opt > Disp Tmp in C

Log Speed in kmh: Menu > Display Opt > Log Spd in kmh

Contrast: Menu > Display Opt > Chg. Contrast > select Increase or Decrease then press middle button

Parachuting is a hazardous activity that can result in injury or death. An altimeter may malfunction, even when properly designed, built, assembled, maintained and used. Do not rely upon an altimeter for your safety. Your altimeter must only be considered as an aid when checking your altitude. The displayed altitude may not be correct during both ascent and descent – a visual cross reference with the ground should be used in combination with the altimeter.

USING N3 AS AN AUDIBLE ALTIMETER

FITTING THE HELMET SLEEVE - 1

Align the N3's speaker with the speaker hole in the helmet sleeve. Failure to do so may result in inaudible alarms.

Using the **Flip** function, the N3 can be fitted with the buttons in either direction, on either side of your helmet. Use the tie wraps to attach the sleeve to the helmet, keeping the speaker hole and speaker aligned.

FITTING THE HELMET SLEEVE - 2

Slide the N3 into the sleeve.

The sleeve is designed to fit in a recess as shown.

ALARMS - 1

Menu > Alarms

On the Menu screen, scroll to and Select **Alarms**.

ALARMS – 2

The currently active FF and Canopy Alarm Groups and the pre-set alarm altitudes will appear.

Scroll to and select **Edit Alarms**.

ALARMS – 3

To change the altitudes of the current Group, **FF1**, select it from the list.

ALARMS - 4

Scroll to select the altitude you want to change.
Increase or decrease alarm altitude. Once you have the desired altitude, scroll to the select OK.

Parachuting is a hazardous activity that can result in injury or death. An altimeter may malfunction, even when properly designed, built, assembled, maintained and used. Do not rely upon an altimeter for your safety. Your altimeter must only be considered as an aid when checking your altitude. The displayed altitude may not be correct during both ascent and descent – a visual cross reference with the ground should be used in combination with the altimeter.